

# 12VDC Tube Driver Board

## G9614

To use your G9614 Fluorescent Tube Driver Circuit Board, do the following:

1. Connect your tube (no polarity needed) to the pads (Labeled "B") on the PC board.
2. Connect the "+" lead of a 12V battery to the pad on the PC board (Labeled "+") and the "-" of the battery (Labeled "-") to the pad on the PC board.
3. Now momentarily connect the 2 silver looking contact points on the component side of the PC board using the spring loaded button and your tube should light for about 1 minute and then turn off. Allow 1 minute for the board to cool and then you may repeat this step. Note: You may want to solder a momentary pushbutton switch to the 2 contact points.

