

# 12VDC Tube Driver Board

## G9614

To use your G9614 Fluorescent Tube Driver Circuit Board, do the following:

1. Connect your tube (no polarity needed) to the pads (Labeled "B") on the PC board.
2. Now solder the 2 silver looking contact points on the component side of the PC board marked "S" to the contacts of a N.O. push button switch (such as G1801) using wire.
3. Connect the "+" lead of a 12V battery to the pad on the PC board (Labeled "+") and the "-" of the battery (Labeled "-") to the pad on the PC board.

Push the button on the switch and your tube should light for about 1 minute and then turn off. Allow 1 minute for the board to cool and then you may repeat this step.

