

G19899

Rechargeable Submersible Water Pump

PUMP OPERATION

1 BATTERY INSTALLATION

Note: Fully charge battery before using. Look at arrow on knob and line up with arrow on pump. Insert knob.

2 TO OPERATE THE PUMP

When OFF, the arrow will be pointed to the dot on the left of the handle base. To turn ON, turn the knob clockwise so the arrow aligns with the dot on the right of the handle base.

PUMP ASSEMBLY

3 ATTACHING HOSE

Using hose provided or standard garden hose, firmly attach hose end to threads on side of pump.

4 STRAINER REMOVAL

4.a) Simultaneously PRESS buttons on each side off pump directly above strainer.

4.b) When the strainer releases, pull it evenly out of the bottom of the pump.

CHARGING INSTRUCTIONS

5 TO REMOVE BATTERY PACK

5.a) PRESS release button on side of pump.

5.b) Turn the knob counterclockwise from the OFF position to point to the arrow on the side of the pump.

5.c) When properly aligned, remove battery.

6 CHARGER BASE OPERATION

Set battery securely in base. The light indicates charge of battery.


Green = Ready

Yellow = Charging


Red = Disconnect power cord and reconnect to charger base.

Note: Battery needs to be charged before use. Please charge for 14 hours to bring battery to full charge.


1




2




OFF



ON




3




4

4.a)




4.b)



5


5.a)



5.b)



5.c)



6

